# TARGET 250-500-1000

# ASSEMBLY AND OPERATING INSTRUCTIONS:

COD. 406008 COD. 406006 COD. 406007



-very low voltage feeding with security transformer -Class III no earth required



In the case of glass breakage, contact the device manufacturer to replace it. Replace the screen with an original replacement



-getting rid of as urban waste forbidden -separate collection is mandatory when the product is at the




Made in Italy

ix i

#### -Retain the instructions

NB: The appliance must not be tampered with or transformed and it must be installed and used as supplied and in compliance with the National Rules on Installations. Any non-compliant installations will invalidate all forms of guarantee. The company cannot be held responsible for damage caused by incorrect assembly.



#### THE WARRANTY IS FALLING IN THE FOLLOWING CASES:

1) Malfunctions due to improper use of the product, modifications, repairs inadequate, negligence on the part of the installer / electrician, failure to assembly instructions and / or data plate;

2) Installations in plants not comply with the general safety;

3) Damage caused by natural causes such as lightning, fire or flooding;

4) Damage caused by wiring / connections with IP degree lower than the selected product.

5) Damage occurring during shipment of the product. In these cases the damage will be to charge and notify the carrier; 6) The warranty covers only the integrity of the product and NOT any costs of removal of the same;

#### Recommendations

1) verify that the equipment used to connect our devices to enjoy

all the guarantees required under European law;

2) use the cables, connectors and quality materials for electrical wiring;

3) Products with IP65/68 degree make the wiring / connections with accessories provide the same degree IP of the selected product (available in the catalog);

4) In the case of installations outside is not recommended to install the power supplies in the formwork and / or in the junction box without adequate protection;

#### Note on corrosion protection

For installation and maintenance be especially careful not to damage the coating powder . Damage combined action of water could cause corrosion.

-In the case of damage to the external flexible cable, it must be replaced by the manufacturer, or its assistance service, or equivalent qualified personnel in order to avoid dangers

-In the case of glass breakage, contact the device manufacturer to replace it. Replace the screen with an original replacement

-Do not use water high pressure cleaners

#### Installation:


1)Set the apparatus at the point of supply by making the appropriate electrical connection to the line

2) Drill holes in the wall to insert plugs (fischer type) corresponding to the holes located on the base unit.


3) Secure the unit by tightening the screws on the plugs.

4) Position the beam of lighting fixture in the desired way

### ACCESSORIES



## SERIAL CONNECTION SCHEME



AC051 LEADER CABLE